


OPERATING INSTRUCTIONS AND PARTS LIST
FOR
LP-12
25" LAWN SWEEPER



NOTICE: We recommend that the user of our LAWN SWEEPER read all instructions carefully before assembling and operating the Sweeper to obtain the best results. While reading assembly instructions study the assembled view and also the exploded view as to the location and arrangement of parts.

MIAMI, INC.

Box 295

SPRINGFIELD, OHIO

DIVISION OF PARKER SWEEPER COMPANY

Printed in U.S.A.

ASSEMBLY INSTRUCTIONS

1. Install lower handle sections, Ref. No. 38, to inside of sweeper hood, Ref. No. 14, with round head screws, Ref. No. 8, and square nuts, Ref. No. 7. Have square nuts to the inside.
2. Assemble the support handle, Ref. No. 12, to the lower handle sections, Ref. No. 38, with round head screws, Ref. No. 6, and square nuts, Ref. No. 7. Have square nuts to the inside. Hooks in support handle must face forward.
3. Assemble wood roller, Ref. No. 37, to roller bracket, Ref. No. 25, by placing a spacer, Ref. No. 36, through wood roller and positioning roller in bracket and fastening with round head screw, Ref. No. 10, and square nut, Ref. No. 7.
4. Assemble roller assembly to support handle, Ref. No. 12, at center with round head screw, Ref. No. 6, and square nut, Ref. No. 7.

5. Assemble center handle sections (bent), Ref. No. 39 to lower handle sections, Ref. No. 38. Have the bend upward and the formed end on the outside of lower handle sections, with round head screws, Ref. No. 6, and square nuts, Ref. No. 7. Have square nuts to inside.
6. Assemble the upper handle section, Ref. No. 1, to the center handle sections. Also assemble the upper basket brackets, Ref. No. 5, to the handle as shown in exploded view with round head screws, Ref. No. 6, and square nuts, Ref. No. 7. These two nuts may either be to the inside or outside, whichever way is easiest to assemble. Make sure that the openings which receive the basket dowel are upwards.
7. Straighten the basket stiffeners, Ref. No. 40, so they are square. Insert one of them into the canvas basket bottom slots, starting from the rear; the other from the front of the basket bottom. Make sure wires are to inside of basket.

OPERATING INSTRUCTIONS

ADJUSTING BRUSH HEIGHT

The adjustment of this sweeper is very important for its ease of operation.

The adjustment of brushes is controlled by the wing nut in front of sweeper unit. This adjustment will automatically set the hood assembly to the correct position with your brush height selection. The large adjustment range is designed to compensate for brush wear.

1. For grass clippings that just have been cut or loose leaves, adjust brushes to within $\frac{1}{2}$ " above the grass.
2. Patio, Sidewalk and Driveway Sweeping — adjust brushes to touch cement.

NOTE: If sweeper pushes hard, the brushes are set too low.

LUBRICATION

Lubricate the sweeper about once each season to insure long unit life and easy operation.

1. Oil the wheel gears and pinion gears through oil hole on each side of wheel hub.
2. It is not necessary to oil nylon brush bearings.

CARE AND REPLACEMENT OF BRUSHES

The brushes used on this sweeper are made of the finest bristles that will give years of service if given proper care.

Should they become bent from constant use, dampening and straightening will reset the bristles upright. It is also possible to straighten bristles by reversing the brushes on the reel shaft.

To reverse or replace brushes:

1. Turn the sweeper upside down on the ground.
2. Remove the bolts which hold the brush sections to the reel shaft. Reverse and replace the brushes and retighten the bolts.

CANVAS BASKET CARE

The canvas will give longer life if it is never compressed or stored when wet or damp. Allow the canvas to dry thoroughly in upright position before storing.

STORAGE

You can hang the sweeper on the wall by the upper handle for storage.

MIAMI, INC.

Box 295

SPRINGFIELD, OHIO

